

Micro Motion® Model 1700 and 2700

Installation Manual



Safety messages

Safety messages are provided throughout this manual to protect personnel and equipment. Read each safety message carefully before proceeding to the next step.

Emerson Flow customer service

Email:

- Worldwide: flow.support@emerson.com
- Asia-Pacific: APflow.support@emerson.com

Telephone:

North and South America		Europe and Middle East		Asia Pacific	
United States	800-522-6277	U.K.	0870 240 1978	Australia	800 158 727
Canada	+1 303-527-5200	The Netherlands	+31 (0) 704 136 666	New Zealand	099 128 804
Mexico	+41 (0) 41 7686 111	France	0800 917 901	India	800 440 1468
Argentina	+54 11 4837 7000	Germany	0800 182 5347	Pakistan	888 550 2682
Brazil	+55 15 3413 8000	Italy	8008 77334	China	+86 21 2892 9000
Venezuela	+58 26 1731 3446	Central & Eastern	+41 (0) 41 7686 111	Japan	+81 3 5769 6803
		Russia/CIS	+7 495 981 9811	South Korea	+82 2 3438 4600
		Egypt	0800 000 0015	Singapore	+65 6 777 8211
		Oman	800 70101	Thailand	001 800 441 6426
		Qatar	431 0044	Malaysia	800 814 008
		Kuwait	663 299 01		
		South Africa	800 991 390		
		Saudi Arabia	800 844 9564		
		UAE	800 0444 0684		

Contents

Chapter 1	Planning	1
1.1	Meter components	1
1.2	Installation types	1
1.3	Maximum cable lengths between sensor and transmitter	6
1.4	Output options	7
1.5	Environmental limits	8
1.6	Hazardous area classifications	8
1.7	Power requirements	8
1.8	Orientation	9
1.9	Accessibility for maintenance	10
Chapter 2	Mounting and sensor wiring for integral installations	11
2.1	Mounting and sensor wiring	11
2.2	Rotate the transmitter on the sensor (optional)	11
2.3	Rotate the user interface on the transmitter (optional)	13
2.4	Ground the meter components	14
Chapter 3	Mounting and sensor wiring for 4-wire remote installations	16
3.1	Mounting options	16
3.2	Prepare the 4-wire cable	20
3.3	Wire the transmitter to the sensor	23
3.4	Rotate the user interface on the transmitter (optional)	25
3.5	Ground the meter components	26
Chapter 4	Mounting and sensor wiring for 9-wire remote installations	28
4.1	Mounting options	28
4.2	Prepare the 9-wire cable	30
4.3	Wire the transmitter to the sensor using jacketed cable	36
4.4	Wire the transmitter to the sensor using shielded or armored cable	39
4.5	Rotate the user interface on the transmitter (optional)	44
4.6	Ground the meter components	46
Chapter 5	Mounting and sensor wiring for remote core processor with remote sensor installations	48
5.1	Mounting options	48
5.2	Mount the remote core processor	52
5.3	Prepare the 4-wire cable	53
5.4	Wire the transmitter to the remote core processor	56
5.5	Prepare the 9-wire cable	58
5.6	Wire the remote core processor to the sensor using jacketed cable	64
5.7	Wire the remote core processor to the sensor using shielded or armored cable	67
5.8	Rotate the user interface on the transmitter (optional)	71
5.9	Ground the meter components	73
Chapter 6	Wiring the power supply	76
6.1	Wire the power supply	76
Chapter 7	I/O wiring for Model 1700 and Model 2700 transmitters with analog outputs	77
7.1	Basic analog wiring	77
7.2	HART/analog single loop wiring	78

7.3	RS-485 point-to-point wiring	79
7.4	HART multidrop wiring	79
Chapter 8	I/O wiring for Model 1700 and Model 2700 transmitters with intrinsically safe outputs	81
8.1	Safe area mA output wiring	81
8.2	Safe area HART/analog single-loop wiring	82
8.3	Safe area HART multidrop wiring	83
8.4	Safe area frequency output/discrete output wiring	84
8.5	Hazardous area wiring	84
Chapter 9	I/O wiring for Model 2700 transmitters with configurable input/outputs	90
9.1	Channel configuration	90
9.2	mA/HART wiring	91
9.3	Frequency output wiring	93
9.4	Discrete output wiring	97
9.5	Discrete input wiring	101
Chapter 10	I/O wiring for Model 2700 transmitters with Foundation fieldbus or PROFIBUS-PA	103
10.1	Foundation fieldbus wiring	103
10.2	PROFIBUS-PA wiring	104
Chapter 11	Specifications	105
11.1	Electrical connections	105
11.2	Input/output signals	106
11.3	Local display	110
11.4	Environmental limits	111
11.5	Physical specifications	111
Index	116	

1 Planning

Topics covered in this chapter:

- *Meter components*
- *Installation types*
- *Maximum cable lengths between sensor and transmitter*
- *Output options*
- *Environmental limits*
- *Hazardous area classifications*
- *Power requirements*
- *Orientation*
- *Accessibility for maintenance*

1.1 Meter components

The transmitter is one component of a Micro Motion device. The other major component is the sensor.

A third component, called the core processor, provides additional memory and processing functions.

1.2 Installation types

The transmitter was ordered and shipped for one of up to eight installation types. The fifth character of the transmitter model number indicates the installation type.

Figure 1-1: Installation type indication for Model 1700 and Model 2700 transmitters



The model number is located on the device tag on the side of the transmitter.

Table 1-1: Installation types for Model 1700 and Model 2700 transmitters

Model code	Description
R	Remote mount 4-wire
I	Integral

Table 1-1: Installation types for Model 1700 and Model 2700 transmitters (continued)

Model code	Description
E	Remote enhanced core processor (painted aluminum housing) with remote transmitter
C	Remote mount 9-wire (painted aluminum housing)
B	Remote core processor with remote transmitter
M	Remote mount 4-wire (stainless steel housing)
P	Remote mount 9-wire (stainless steel housing)
H ⁽¹⁾	Remote mount 4-wire (painted aluminum housing) for connecting to Compact Density Meter (CDM), Fork Density Meter (FDM), Fork Viscosity Meter (FVM)

(1) This option is only available with the Model 2700 FOUNDATION Fieldbus™ transmitter

Figure 1-2: Integral installation (model code I)

The transmitter is mounted directly to the sensor. Integral installations do not require separate transmitter installation. Power supply and I/O must be field wired to the transmitter.





Figure 1-3: High-temperature meters with factory connection (model code I)


The transmitter is shipped with a flexible connection factory installed between the sensor and the transmitter. The transmitter must be dismounted from its shipping location (spot-welded to the sensor case) and then mounted separately. Power supply and I/O must be field wired to the transmitter.



- A. Sensor
 - B. Transmitter or core processor
 - C. Factory-installed flexible connection
-

Figure 1-4: 4-wire remote installation for Coriolis meters (model code R or M)


The transmitter is installed remotely from the sensor. The 4-wire connection between the sensor and transmitter must be field wired. Power supply and I/O must be field wired to the transmitter.



- A. Transmitter
 - B. Field-wired 4-wire connection
 - C. Core processor
 - D. Sensor
-

Figure 1-5: 4-wire remote installation for density and viscosity meters (CDM, FDM, or FVM with fieldbus only)(model code H)


The transmitter is installed remotely from the Compact Density Meter (CDM), Fork Density Meter (FDM), or Fork Viscosity Meter (FVM). The 4-wire connection between the sensor and transmitter must be field wired. Power supply and I/O must be field wired to the transmitter.



- A. Transmitter
 - B. Field-wired 4-wire connection
 - C. Meter electronics
-

Figure 1-6: 9-wire remote installation (model code P)


The transmitter and core processor are combined in a single unit that is installed remotely from the sensor. The 9-wire connection between the transmitter/core processor and the sensor must be field wired. Power supply and I/O must be field wired to the transmitter.



- A. Transmitter
 - B. Field-wired 9-wire connection
 - C. Junction box
 - D. Sensor
-

Figure 1-7: Remote core processor with remote sensor installation (model code B or E)

The transmitter, core processor, and sensor are all mounted separately. The 4-wire connection between the transmitter and core processor must be field wired. The 9-wire connection between the core processor and the sensor must be field wired. Power supply and I/O must be field wired to the transmitter. This configuration is sometimes called double-hop.



- A. Junction box
- B. Sensor
- C. Transmitter
- D. Field-wired 4-wire connection
- E. Core processor
- F. Field-wired 9-wire connection

1.3

Maximum cable lengths between sensor and transmitter

The maximum cable length between the sensor and transmitter that are separately installed is determined by cable type.

Table 1-2: Maximum cable lengths between sensor and transmitter

Cable type	Wire gauge	Maximum length
Micro Motion 4-wire	Not applicable	<ul style="list-style-type: none"> • 1000 ft (300 m) without Ex-approval • 500 ft (150 m) with IIC rated sensors • 1000 ft (300 m) with IIB rated sensors
Micro Motion 9-wire	Not applicable	60 ft (20 m)
User-supplied 4-wire	VDC 22 AWG (0.35 mm ²)	300 ft (90 m)