



Level



Pressure



Flow



Temperature



Liquid  
Analysis



Registration



Systems  
Components



Services




Solutions

## Operating Instructions

# Deltatop DP61D, DP62D, DP63D

Pitot tubes for differential pressure flow measurement





## Table of contents

<b>1</b>	<b>Safety instructions</b>	<b>4</b>	7.6	Disposal	48
1.1	Designated use	4	7.7	Contact addresses of Endress+Hauser	48
1.2	Installation, commissioning, operation	4	<b>8</b>	<b>Accessories</b>	<b>49</b>
1.3	Hazardous area	4	8.1	Overview	49
1.4	Notes on safety conventions and symbols	5	8.2	Purge unit DA62P	50
<b>2</b>	<b>Identification</b>	<b>6</b>	8.3	Oval flange adapter PZO	53
2.1	Nameplate	6	<b>9</b>	<b>Appendix</b>	<b>54</b>
2.2	Product structure	6	9.1	Measuring principle	54
2.3	Documentation	7	9.2	Flow calculation	55
2.4	Certificates and approvals	9	<b>Index</b>	<b>57</b>	
2.5	Registered trademarks	9			
<b>3</b>	<b>Installation</b>	<b>10</b>			
3.1	Incoming acceptance, transport, storage	10			
3.2	Dimensions	10			
3.3	Mounting position for liquid applications	11			
3.4	Mounting position for gas applications	12			
3.5	Mounting position for steam applications	13			
3.6	General mounting conditions	15			
3.7	General mounting hints	19			
3.8	Installation steps for the cutting ring version	20			
3.9	Installation steps for the flange version	22			
3.10	Installation steps for the Flowtap version with safety chain	24			
3.11	Installation steps for the Flowtap version with spindle	27			
3.12	Installation steps for a Flowtap version with flange	30			
3.13	Installation check	34			
<b>4</b>	<b>Wiring</b>	<b>35</b>			
4.1	Wiring of the Deltabar S differential pressure transmitter	35			
4.2	Wiring of the integrated Pt100 temperature sensor	36			
<b>5</b>	<b>Operation and commissioning</b>	<b>38</b>			
5.1	Configuration of the Deltabar S differential pressure transmitter	38			
5.2	Configuration of a temperature and pressure compensation	38			
5.3	Usage of the accessories	40			
<b>6</b>	<b>Troubleshooting</b>	<b>44</b>			
6.1	Error messages of the Deltabar S	44			
6.2	Application errors	45			
<b>7</b>	<b>Maintenance and repairs</b>	<b>46</b>			
7.1	Maintenance	46			
7.2	Exterior cleaning	46			
7.3	Replacing seals	46			
7.4	Spare parts	47			
7.5	Return	48			

# 1 Safety instructions

## 1.1 Designated use

The measuring system is used to measure the volume or mass flow of saturated steam, over-heated steam, gases and liquids.

Resulting from incorrect or from use other than that designated the operational safety of the measuring devices can be suspended. The manufacturer accepts no liability for damages being produced from this.

## 1.2 Installation, commissioning, operation

The Deltatop measuring system is fail-safe and is constructed to the state-of-the-art. It meets the appropriate standards and EC directives. However, if you use it improperly or other than for its designated use, it may pose application-specific hazards, e.g. product overflow due to incorrect installation or configuration. Installation, electrical connection, start-up, operation and maintenance of the measuring device must therefore be carried out exclusively by trained specialists authorised by the system operator. Technical personnel must have read and understood these operating instructions and must adhere to them. You may only undertake modifications or repair work to the device when it is expressly permitted by the operating instructions.













## 1.3 Hazardous area

Measuring systems for use in hazardous environments are accompanied by separate "Ex documentation", which is an integral part of this Operating Manual. Strict compliance with the installation instructions and ratings as stated in this supplementary documentation is mandatory.

- Ensure that all personnel are suitably qualified.
- Observe the specifications in the certificate as well as national and local standards and regulations.




## 1.4 Notes on safety conventions and symbols

In order to highlight safety-relevant or alternative operating procedures in the manual, the following conventions have been used, each indicated by a corresponding symbol in the margin.

Safety conventions	
	<p><b>Warning!</b> A warning highlights actions or procedures which, if not performed correctly, will lead to personal injury, a safety hazard or destruction of the instrument</p>
	<p><b>Caution!</b> Caution highlights actions or procedures which, if not performed correctly, may lead to personal injury or incorrect functioning of the instrument</p>
	<p><b>Note!</b> A note highlights actions or procedures which, if not performed correctly, may indirectly affect operation or may lead to an instrument response which is not planned</p>
Explosion protection	
	<p><b>Device certified for use in explosion hazardous area</b> If the device has this symbol embossed on its name plate it can be installed in an explosion hazardous area</p>
	<p><b>Explosion hazardous area</b> Symbol used in drawings to indicate explosion hazardous areas. Devices located in and wiring entering areas with the designation “explosion hazardous areas” must conform with the stated type of protection.</p>
	<p><b>Safe area (non-explosion hazardous area)</b> Symbol used in drawings to indicate, if necessary, non-explosion hazardous areas. Devices located in safe areas still require a certificate if their outputs run into explosion hazardous areas</p>
Electrical symbols	
	<p><b>Direct voltage</b> A terminal to which or from which a direct current or voltage may be applied or supplied</p>
	<p><b>Alternating voltage</b> A terminal to which or from which an alternating (sine-wave) current or voltage may be applied or supplied</p>
	<p><b>Grounded terminal</b> A grounded terminal, which as far as the operator is concerned, is already grounded by means of an earth grounding system</p>
	<p><b>Protective grounding (earth) terminal</b> A terminal which must be connected to earth ground prior to making any other connection to the equipment</p>
	<p><b>Equipotential connection (earth bonding)</b> A connection made to the plant grounding system which may be of type e.g. neutral star or equipotential line according to national or company practice</p>
	<p><b>Temperature resistance of the connection cables</b> States, that the connection cables must be resistant to a temperature of at least 85 °C.</p>

## 2 Identification

### 2.1 Nameplate

<p><b>Endress+Hauser</b>  </p> <p><b>Deltatop</b></p> <p>Made in Germany, D-79689 Maulburg</p> <p>Order Code: <input type="text"/></p> <p>Ident.No.: <input type="text"/></p> <p>Serial No.: <input type="text"/></p> <p>Pipe ID: <input type="text"/></p> <p>K-Faktor: <input type="text"/></p> <p>Wall thickness: <input type="text"/></p> <p>Press. rate: <input type="text"/></p> <p style="text-align: right;">25002572—</p>	<p></p> <p>Mat.of primary: <input type="text"/></p> <p>Fluid: <input type="text"/></p> <p>Flow rate: <input type="text"/></p> <p>Calc. dP value: <input type="text"/></p> <p>Pressure: <input type="text"/></p> <p>Temperature: <input type="text"/></p> <p style="text-align: right;">25002573—</p>
---	---

P01-DPxxxxxx-18-xx-00-xx-002

**Order Code:** Order code of the instrument according to the product structure (see Technical Information TI425P)

**Ident. No.:** Identification number; characterizes the instrument unambiguously

**Serial No.:** Serial number

**Pipe ID:** Inner diameter of the measuring pipe

**K-Faktor:** Flow coefficient of the Pitot tube

**Wall thickness:** wall thickness of the measuring pipe

**Press. rate:** pressure rating

**Mat. of primary:** Material of the Pitot tube

**Fluid:** Fluid for which the instrument has been sized

**Flow rate:** Flow rate for which the instrument has been sized (operating point)

**Calc dP value:** calculated differential pressure at the operating point

**Pressure:** operating pressure

**Temperature:** operating temperature

### 2.2 Product structure

See Technical Information TI 425P.

## 2.3 Documentation

### 2.3.1 Deltatop

Document	Device	Designation
<b>Technical Information</b>		
TI422P	DO61W, DO62C, DO63C, DO64P, DO65F	Differential pressure flow measurement with orifices and Deltabar differential pressure transmitter
TI425P	DP61D, DP62D, DP63D	Differential pressure flow measurement with Pitot tubes and Deltabar differential pressure transmitter
<b>Operating Instructions</b>		
BA368P	DO61W, DO62C, DO63C, DO64P, DO65F	Differential pressure flow measurement with orifices and Deltabar differential pressure transmitter
BA369P	DP61D, DP62D, DP63D	Differential pressure flow measurement with Pitot tubes and Deltabar differential pressure transmitter

### 2.3.2 Deltabar S

Document	Device	Designation
<b>Technical Information</b>		
TI382	Deltabar S	Differential pressure transmitter
<b>Operating Instructions</b>		
BA270P	Deltabar S	Differential pressure transmitter - HART
BA294P	Deltabar S	Differential pressure transmitter - PROFIBUS PA
BA301P	Deltabar S	Differential pressure transmitter - FOUNDATION FIELDBUS
<b>Description of Instrument Functions</b>		
BA274P	Cerabar S/Deltabar S/Deltapilot S	Pressure and differential pressure transmitter HART
BA296P	Cerabar S/Deltabar S/Deltapilot S	Pressure and differential pressure transmitter PROFIBUS PA
BA303P	Cerabar S/Deltabar S/Deltapilot S	Pressure and differential pressure transmitter FOUNDATION FIELDBUS
<b>Safety Instructions (ATEX)</b>		
XA235P	Deltabar S	ATEX II 1/2 G EEx ia
XA237P	Deltabar S	ATEX II 1/2 D
XA239P	Deltabar S	ATEX II 1/3 D
XA240P	Deltabar S	ATEX II 2G EEx d
XA241P	Deltabar S	ATEX II 3 G EEx nA
XA242P	Deltabar S	ATEX II 1/2 G EEx id; ATEX II 2 G EEx d
XA243P	Deltabar S	ATEX II 1/2 GD EEx ia
XA275P	Deltabar S	ATEX II 1 GD EEx ia

### 2.3.3 Omnigrad T (RTD resistance thermometer) iTEMP (temperature head transmitter)

Document	Device	Designation
<b>Technical Information</b>		
TI269T	Omnigrad T TR24	RTD resistance thermometer
TI070R	iTEMP TMT181	temperature head transmitter 4...20 mA
TI078R	iTEMP TMT182	temperature head transmitter HART
TI079R	iTEMP TMT184	temperature head transmitter PROFIBUS PA
<b>Operating Instructions</b>		
KA141R	iTEMP TMT181	temperature head transmitter 4...20 mA
KA142R	iTEMP TMT182	temperature head transmitter HART
BA115R	iTEMP TMT184	temperature head transmitter PROFIBUS PA
<b>Safety Instructions (ATEX)</b>		
XA003T	Omnigrad T TR24	ATEX II 1 GD EEx ia IIC
XA004R	iTEMP TMT181 (4...20 mA)	ATEX II 1 G EEx ia IIC
XA006R	iTEMP TMT182 (HART)	ATEX II 1 G EEx ia IIC
XA008R	iTEMP TMT184 (PROFIBUS PA)	ATEX II 1 G EEx ia IIC

### 2.3.4 Flow and Energy Manager RMS621/RMC621

Document	Device
<b>Technical Information</b>	
TI092R	Energy Manager RMS621
TI098R	Flow and Energy Manager RMC621
<b>Operating Instructions</b>	
BA127R	Energy Manager RMS621
BA144R	Flow and Energy Manager RMC621



## **2.4 Certificates and approvals**

### **2.4.1 CE mark, declaration of conformity**

The device is designed to meet state-of-the-art safety requirements, has been tested and left the factory in a condition in which it is safe to operate. The device complies with the applicable standards and regulations as listed in the EC declaration of conformity and thus complies with the statutory requirements of the EC directives. Endress+Hauser confirms the successful testing of the device by affixing to it the CE mark.

### **2.4.2 European Pressure Equipment Directive 97/23/EC (PED)**

Deltatop Pitot tubes comply with article 3.3 of the Pressure Equipment Directive 97/23/EC and thus have no CE mark affixed to them.

## **2.5 Registered trademarks**

HART®

Registered trademark of HART Communication Foundation, Austin, USA

PROFIBUS®

Registered trademark of the PROFIBUS Trade Organisation, Karlsruhe, Germany

FOUNDATION Fieldbus®

Registered trademark of the Fieldbus Foundation Austin, Texas, USA

VITON®

Registered trademark of the company, E.I. Du Pont de Nemours & Co., Wilmington, USA

Ermeto®

Registered trademark of the Parker Hannifin GmbH, Bielefeld, Germany

## 3 Installation

### 3.1 Incoming acceptance, transport, storage

#### 3.1.1 Incoming acceptance

Check the packing and contents for any sign of damage.

Check the shipment, make sure nothing is missing and that the scope of supply matches your order.

#### 3.1.2 Transport



Caution!

Follow the safety instructions and transport conditions for instruments of more than 18 kg.

Do not lift the measuring instrument by the housing of the transmitter in order to transport it.

#### 3.1.3 Storage

For storing and transport, shock proof packaging of the measuring instrument is required. The original packaging material provides optimum protection.

The permissible storage temperature for the Deltabar transmitter is  $-40\text{ °C} \dots +80\text{ °C}$ .

### 3.2 Dimensions

See Technical Information TI425P.