

Instruction Manual

Hydraulic Drum Truck



DT250



DTR250



DTW250

Note: The Owner/Operator must read carefully and understand all the information presented here before operation.

Content

1.	Figure and Dimension.....	2
1.1	Figure.....	2
1.1.1	DT250.....	2
1.1.2	DTR250.....	3
1.1.3	DTW250.....	3
1.2	Technical Specification.....	4
2.	Part Name.....	4
3.	Warning.....	4
4.	Installation and Operation.....	5
4.1	Installation.....	5
4.2	Operation.....	5
4.2.1	Lift drum.....	5
4.2.2	Transport drum.....	5
4.2.3	Put down drum.....	6
5	Maintenance.....	6
6	Hydraulic Circuit Diagram.....	7
7	Exploded View & Part List.....	8
7.1	DT250 Exploded View & Part List.....	8
7.2	DTR250 Exploded View & Part List.....	11
7.2	DTW250 Exploded View & Part List.....	14

THANK YOU FOR USING THIS HYDRAULIC DRUM TRUCK. FOR YOUR SAFETY AND CORRECT OPERATION, PLEASE CAREFULLY READ THIS INSTRUCTION BEFORE USING IT.


NOTE: All of the information reported herein is based on data available at the moment of printing. The factory reserves the right to modify its own products at any moment without notice and incurring in any sanction. So it is suggested to always verify possible updates.

This hydraulic drum truck is used to clamp the drum on the ground or stock for load and unload, transit, stack the drum. It is used widely to factory, depot and etc.


1. FIGURE AND PARAMETER

1.1 Figure


1.1.1 DT250 (It is used to load and unload, transit the drum on the ground)



1.1.2 DTR250 (It is used to load and unload by stock or transit the drum)



1.1.3 DTW250 (It is used to load and unload by stock or transit the drum)



1.2 Technical Parameter

Model	DT250	DTR250	DTW250
Capacity (kg)	250	250	250
Suitable for Drum Diameter (mm)	572	572	572
Pump Stroke (mm)	345	300	345
Overall Size (L×W×H) (mm)	820×800×1050	812×980×1100	820×1015× 1050
Net Weight (kg)	45	50	45

2. PART NAME

- (1) Swivel Wheel (Versatile Wheel)
- (2) Fork Assy.
- (3) Cylinder Assy.
- (4) Screw
- (5) Handle
- (6) Discharge Joystick
- (7) Lever
- (8) Clamp
- (9) Leg
- (10) Front Wheel
- (11) Bolt
- (12) Chassis

3. WARNING

- 3.1 Never use the drum truck when it has failure.
- 3.2 Never overload this truck beyond its rated capacity.
- 3.3 Place the drum on the low position when do not lift.
- 3.4 Raise slightly the drum on the ground when transit drum, do not

need lift it higher.

4. INSTALLATION AND OPERATION

4.1 INSTALLATION

- (1) Open the packing, take out the fork assembly (2), cylinder assembly (3), screw (4), handle (5), bolt (11) and chassis (12) and ensure the parts are full.
- (2) Fix the fork assembly (2) and chassis (12) with bolt (11).
- (3) Place the cylinder assembly (3) on the chassis (12) and fix it with screw (4).
- (4) Insert the handle (5) in the pump seat on the cylinder assembly (3) and clamp it with the screw.

4.2 OPERATION INSTRUCTION

4.2.1 Lift drum

Screw handle (5) clockwise, and then move the transporter so as to make the lifting frame contact with drum.

Repeatedly press the handle (5) to pump up the lifting frame so that the upper edge of drum is between the clamp's teeth and the teeth on the upper end of lifting frame.

Then push the bulbous knob connected to clamp (8) to allow the clamp to grab the drum firmly and for the bulbous knob to lock the clamp (8).

Continue to pump up the lifting frame by handle (5) and the drum will be lifted.

4.2.2. Transport drum

Push / pull the handle (5) to move the transporter to the destination. (Of course, if necessary, operator can turn the handle to change the transporter's moving direction.)

For the sake of safety it is recommended to move the loaded transporter

while the drum's position is as low as possible.

4.2.3 Put down drum

Slowly screw handle (6) counterclockwise and lower the drum till it stands on the floor.

Pull the bulbous knob back to unlock position so as to release the clamp.

Warning: It is forbidden to screw handle (6) anticlockwise rapidly in case of damage of the drum or the transporter.

5. MAINTENANCE

1. Do routine check of chassis (Part No. 12) and front rear wheels. Especially make sure that rear caster is firm.
2. Do routine check of packing.
3. It is feasible and recommended to change hydraulic oil while changing packing. It is suggested to use equivalent performance hydraulic oil.


Use different hydraulic oil according to temperature scale below.

Temperature	Hydraulic Oil
-5°C ~ +45°C	L-HM68 Hydraulic oil (equivalent to ISO VG68)
-15°C ~ -5°C	L-HM46 Hydraulic oil (equivalent to ISO VG46)

4. Do routine check of the clamp's tooth. Replace it if tooth wears out seriously.
5. Do routine check of all the connecting parts such as pins and fasteners.


6. HYDRAULIC CIRCUIT DIAGRAM

No.	Description
1	Hydraulic Cylinder
2	Swivel Discharge Valve
3	Relief valve
4	Work valve
5	Work Cylinder



7. EXPLODED VIEW & PART LIST

7.1 DT250 EXPLODED View & Part List



No.	Description	Qty	No.	Description	Qty
1	Nut	1	39	Ring	1
2	Locking Washer	1	40	Bearing	1
3	Swivel Wheel	1	41	Ball	1
4	Chassis	1	42	Lever	1
5	Pin	2	43	Plunger Lever	1
6	Retaining Ring	4	44	Dustproof Ring	1
7	Locking Ring	4	45	O-ring	2
8	Front Wheel	2	46	Washer	1
9	Bearing	4	47	Plunger Casing	1
10	Hexagon Socket Screw	2	48	Cylindroids Tube	1
11	Washer	2	49	Sealing Board	1
12	Spring	2	50	Supported Board	4
13	Steel Ball	2	51	Plunger Casing	1
14	Connected Board	1	52	Pin	1
15	Fixed Board	1	53	Split Pin	1
16	Torsional Spring	1	54	O-ring	2
17	Screw	2	55	Steal Ball	1
18	Nut	2	56	Bushing	1
19	Located Ring	2	57	Plunger Board	1
20	Discharge Lever	1	58	Plunger Casing	1
21	O-ring	1	59	Washer	1
22	Screw	1	60	O-ring	2
23	Roller	2	61	Dustproof Ring	1
24	Bearing	2	62	Spring	1
25	Pin	2	63	Spring Cover	1