

Table 6-4 — Parts List (Continued)

PART NUMBER	DESCRIPTION	
* 51107595-100	WINCHESTER PS	Power Supply
* 51196243-100	445 MEGABYTE DRIVE	History Module Hard Disk Drive
* 51196680-100	512 MEGABYTE DRIVE	History Module Hard Disk Drive
51304395-100	WREN INTF CABLE	Signal Cable from SPC I/O to WREN III
51109181-010	LCN CABLE SET	Standard cable set (for LCN Upgrade)
51401551-XXX	K2LCN BOARD	High Performance Processor w/Memory
* 80360206-001	CLI BOARD	Computer Interface Board
* 51196701-100	CLI/A - EMC	Computer Interface Board (RS449)
80360209-001	CLI I/O ADAPTER	CLI Paddleboard (RS232D)
80360230-001	CLI I/O ADAPTER	CLI Paddleboard (RS449)
51401669-100	FAN ASSEMBLY	Micro Fan Module Assembly

* ORU Level Replacement Item

Table 6-5— Parts List, LCN Upgrade for 3, 4, 5, or 6 Nodes

PART NUMBER	DESCRIPTION	
51109806-002	LCN CABLE SET (RG59)	Two Meter Cable Set
30732052-001	BNC PLUG TERMINATOR	Termination Module
51107403-100	LOCAL CNTL NTWK TRNSCV	Local Control Network Transceiver
51190728-105	CONN BNC	T Connector

Spare parts for the Multinode Module and its components (fan, power supply, boards, etc.) are listed in the *8-Node Multinode Module Service* manual in the *Implementation/8-Node Enhanced Micro TDC 3000* binder. Spare parts for the Five/Ten-Slot Module and its components (fan, power supply, boards, etc.) are listed in the *Five/Ten-Slot Module Service* manual in the *LCN Service - 2* binder.