

SERVICE AND PARTS

Replacement Parts List

Sensor

Furnace Assembly 120VAC	P/N 7000-872-SE
Furnace Assembly 230VAC	P/N 7000-873-SE
Kit, WDG-V Replacement Thermocouple for O ₂ Cell Furnace	P/N 7000-839-TE
Peripherals and I/O Connection Board Assembly	P/N 8000-120-SE
Cell O-Ring Metal	P/N 42005JE
Zirconia Cell	P/N 7000-568-SE
Main Processor Board	P/N 8000-119-SE
Cell Clip-Inside	P/N 72329SE
Cell Clip-Outside	P/N 72328SE
Coil Heater 300W - Furnace - 115VAC	P/N 7000-424-KE
Coil Heater 300W - Furnace - 230VAC	P/N 7000-563-KE
RTD-Box Temp Control - 100 Ohm	P/N 1000-630-JE
Solenoid NO Asp RCU	P/N 36088JE
Solenoid NC Cal Gas RCU	P/N 36090JE
Flowmeter 0-10 LPM	P/N 3000-366-JE
Customer Connection Board	P/N 8000-123-SE
Power Supply 12VDC	P/N 1000-616-JE
Display Board	P/N 8000-122-SE

Remote Calibration Unit (RCU)

Air Regulator	P/N 39003JE
Regulator Gauge	P/N 37013JE
Aspirator Air Solenoid Valve	P/N 36022JE
Calibration Gas Solenoid Valve	P/N 36023JE
Flow Meter (O ₂ -Only RCU)	P/N 37030JE
Flow Meter (Combustibles RCU)	P/N 37020JE