







3SB3 Pushbuttons and Indicator Lights, 22 mm

Accessories and spare parts

Protective covers

Version	Use	Color	DT	Order No.	Price per PU	PU (UNIT, SET, M)	PS*	PG	
Other protective caps¹⁾									
	Sealable caps For round version	Flat button (plastic)	Black	B	3SB19 02-0AL		1	1 unit	41J
		Flat button (metal), raised button (plastic)	Clear	B	3SB19 02-2AR		1	1 unit	41J
									
	Dust covers For use in dusty environments	BKS, CES, O.M.R. key-operated switch	Clear	B	3SB39 21-0BT		1	1 unit	41J
	Protective collars for EMERGENCY-STOP²⁾ For round version	EMERGENCY-STOP mushroom pushbutton without key-operated switch	Yellow	▶	3SB39 21-0AK		1	1 unit	41J
		EMERGENCY-STOP mushroom pushbutton with key-operated switch	Gray	C	3SB39 21-0AP		1	1 unit	41J
		EMERGENCY-STOP mushroom pushbutton with key-operated switch	Yellow	B	3SB39 21-0AX		1	1 unit	41J
	Protective collars for EMERGENCY-STOP for 5 padlocks²⁾ For round version	3SB3...-1AA20 EMERGENCY-STOP mushroom pushbutton	Yellow	▶	3SB39 21-0CG		1	1 unit	41J
	Sun collars For round version	Illuminated pushbuttons	Black	B	3SB39 21-0AS		1	1 unit	41J
Blanking plugs for spare command points for front plates									
	Blanking plugs For round version	Plastic version	Black	▶	3SB39 21-0AA		1	10 units	41J
	Blanking plugs For square version	Plastic version	Black	B	3SB39 41-0AA		1	1 unit	41J
	Blanking plugs (plastic) for round version	Metal version	Alu-minized	B	3SB19 02-0AQ		1	10 units	41J

¹⁾ Not suitable for mounting in 3SB38 enclosures.
Not to be used with label holder.

²⁾ The protective collar must only be used to protect against inadvertent actuating and must be fitted to allow unimpeded actuation of the EMERGENCY-STOP mushroom pushbutton.