

**10 Housing - for E+H service only!****11 Hood for terminal compartment**

52005643 Hood T12

**12 Screw set**

535720-9020 Set of screws housing F12/T12/F23

**20 Cover**

52005936 Cover F12/T12 Aluminium, window, gasket

517391-0011 Cover F12/T12 Aluminium, coated, gasket

**25 Cover for terminal compartment**

518710-0020 Cover T3/T12, Aluminium, coated, gasket

**30 Electronics**

71026754 Electronics FMR24x/FMR250, Ex, HART, v5.0

71026819 Electronics FMR24x/FMR250, Ex, PA, v5.0

71026820 Electronics FMR24x/FMR250, Ex, FF, v5.0

**31 HF module**

71026572 HF module FMR24x, 26 GHz, v5.0

Version: uP III.5

Usage: for electronics from software version 5.0

Micropilot M FMR240/FMR244/FMR245

52024953 HF module FMR24x, FMR259, 26 GHz

version: uP III.3

Usage: for electronics from software version 1.0

Micropilot M FMR250

Usage: for electronics from software version 5.0

Micropilot M FMR24x, advanced dynamics

**35 Terminal module / power supply board**

52013302 Terminal module 4pole, 2-wire, HART, EEx d

52013303 Terminal module 2pole, 2-wire, PROFIBUS PA / FOUNDATION Fieldbus, EEx d

52018949 Terminal module 4pole, 2-wire, HART, EEx ia, overvoltage protection

52018950 Terminal module 4pole, 2-wire, PROFIBUS PA / FOUNDATION Fieldbus, EEx ia, overvoltage protection

**40 Display**

52026443 Display VU331, version 2