




## Adapter Set












 Specific adapter sets with compatible lubrication pins for different drive modules



Assembly instructions

## Technical data



## Ordering codes

	No.
Adapter set LU 2 for AS 2/C-100, AS 2/C-250, BS 2/C, HQ 2/C-H	384254348 3
LU 2 adapter set for AS 2/C-400, AS 2/C-700, BS 2/C-H 1)	384254348 4
LU 2 adapter set for AS 2/R-300, AS 2/R-700, BS 2/R, BS 2/R-H with RV = 1, BS 2/G-250, HQ $^{2}$	384254348 5
LU 2 adapter set for AS 2/R-1200, AS 2/R-2200, BS 2/R-H with RV = 0 3)	384254348 6
LU 2 adapter set for AS 2/R-V-1200, AS 2/R-V-2200, BS 2/R-V-1200 <sup>4)</sup>	384254348 7
LU 2 adapter set for HQ 2/U-H	384254857

- 1) LU 2: AS 2/C-400 and AS 2/C-700 (assembly on UM 2/C-170 when b = 160 mm); BS 2/C-H (assembly on UM 2/C-170; UM 2/R-170 when b = 160 mm)
- 2) LU 2: BS 2/R-H with RV = 1: assembly on UM return unit
- 3) LU 2: AS 2/R-1200 and AS 2/R-2200 (assembly on UM 2/R-170 when b = 160 mm); BS 2/R-H with RV = 0 (assembly on UM 2/C-170; UM 2/R-170 when b = 160 mm)
- 4) LU 2: Assembly on UM 2/R-170 when b = 160 mm