# X20(c)BR9300

## **1** General information

The bus receiver is used to connect the X20 System to the X2X Link. The module is equipped with a feed for the X2X Link as well as the internal I/O supply.

The left and right end plates are included in the delivery.

- X2X Link bus receiver
- Feed for X2X Link and internal I/O supply
- · Electrical isolation of feed and X2X Link supply
- Redundancy of X2X Link supply possible by operating multiple supply modules simultaneously
- · Operation only on the slot to the far left

## 2 Coated modules

Coated modules are X20 modules with a protective coating for the electronics component. This coating protects X20c modules from condensation and corrosive gases.

The modules' electronics are fully compatible with the corresponding X20 modules.

# For simplification purposes, only images and module IDs of uncoated modules are used in this data sheet.

The coating has been certified according to the following standards:

- Condensation: BMW GS 95011-4, 2x 1 cycle
- Corrosive gas: EN 60068-2-60, Method 4, Exposure 21 days



## 3 Order data

Model number	Short description	Figure
	Bus receivers and transmitters	-
X20BR9300	X20 bus receiver, X2X Link, supply for X2X Link and inter- nal I/O supply, X20 locking plates (left and right) X20AC0SL1/ X20AC0SR1 included	33
X20cBR9300	X20 bus receiver, coated, X2X Link, supply for X2X Link and in- ternal I/O supply, X20 locking plates (left and right) X20AC0SL1/ X20AC0SR1 included	CC NG CC X
	Required accessories	
	Bus modules	A 12
X20BM01	X20 power supply bus module, 24 VDC keyed, internal I/O sup- ply interrupted to the left	
X20cBM01	X20 power supply bus module, coated, internal I/O supply inter- rupted to the left	3-
	Terminal blocks	1 -
X20TB12	X20 terminal block, 12-pin, 24 VDC keyed	
	Optional accessories	2
	X2X Link cable	
X67CA0X99.1000	Cable for custom assembly, 100 m	
X67CA0X99.5000	Cable for custom assembly, 500 m	

Table 1: X20BR9300, X20cBR9300 - Order data

## Information:

This module is NOT PERMITTED to be used together with continuous power supply modules (e.g. X20BM11 or X20BM15) since this can result in problems with X2X Link!

# 4 Technical data

Product ID	X20BR9300	X20cBR9300
Short description	· · · · · · · · · · · · · · · · · · ·	
Bus receiver	X2X Link bus receiver with	n supply for I/O and bus
General information		
B&R ID code	0x1BC1	0xDD48
Status indicators	X2X bus function, overload, op	erating status, module status
Diagnostics		5
Module run/error	Yes, using status L	ED and software
Overload	Yes, using status L	ED and software
X2X bus function	Yes, using s	tatus LED
Power consumption 1)		
Bus	1.62	W
Internal I/O	0.6 \	N
Additional power dissipation caused by the actua- tors (resistive) [W]	-	
Electrical isolation		
I/O feed - I/O supply	No	1
X2X Link feed - X2X Link supply	Yes	6
Certification		
CE	Yes	3
cULus	Yes	6
cCSAus HazLoc Class 1 Division 2	Yes	-
ATEX Zone 2 <sup>2)</sup>	Yes	3
КС	Yes	-
GOST-R	Yes	3
X2X Link input supply		
Input voltage	24 VDC -15	% / +20%
Input current	Max. 0	.7 A
Fuse	Integrated, canno	ot be replaced
Reverse polarity protection	Yes	3
X2X Link supply output		
Nominal output power	7 W	V
Parallel operation	Yes	3)
Redundant operation	Yes	8
Overload behavior	Short circuit / temporar	y overload protection
Input I/O supply		
Input voltage	24 VDC -15	% / +20%
Fuse	Required line fuse: Ma	ax. 10 A, slow-blow
Reverse polarity protection	No	
Output I/O supply		
Rated output voltage	24 VI	00
Behavior if a short circuit occurs	Required I	ine fuse
Permitted contact load	10 /	A
Operating conditions		
Mounting orientation		
Horizontal	Yes	8
Vertical	Yes	6
Installation at elevations above sea level		
0 to 2000 m	No limita	ations
>2000 m	Reduction of ambient tempe	rature by 0.5°C per 100 m
EN 60529 protection	IP2	0
Environmental conditions		
Temperature		
Operation		
Horizontal installation	-25 to 6	50°C
Vertical installation	-25 to 5	50°C
Derating	See section	"Derating"
Storage	-40 to 8	35°C
Transport	-40 to 8	35°C

Table 2: X20BR9300, X20cBR9300 - Technical data

### X20(c)BR9300

Product ID	X20BR9300	X20cBR9300
Relative humidity		
Operation	5 to 95%, non-condensing	Up to 100%, condensing
Storage	5 to 95%, no	n-condensing
Transport	5 to 95%, no	n-condensing
Mechanical characteristics		
Note	Order 1x X20TB12 terminal block separately	Order 1x X20TB12 terminal block separately
	Order 1x X20BM01 supply bus module separately	Order 1x X20cBM01 supply bus module separately
	Left and right X20 locking plates included in delivery	Left and right X20 locking plates included in delivery
Spacing	12.5 +	<sup>0.2</sup> mm
Tabl	e 2: X20BR9300, X20cBR9300 - Technica	I data

1) The specified values are maximum values. The exact calculation is also available for download as a data sheet with the other module documentation on the B&R website.

2) Ta min.: 0°C

Ta max.: See environmental conditions

3) In parallel operation, only 75% of the rated power can be assumed. It is important to make sure that all power supplies operating in parallel are switched on and off at the same time.

## **5 LED status indicators**

For a description of the various operating modes, see the section "re LEDs" in chapter 2 "System characteristics" of the X20 system user's manual.

Figure	LED	Color	Status	Description
	r	Green	Off	No power to module
			Single flash	RESET mode
		Blinking PREOPERATIONAL mode		PREOPERATIONAL mode
			On	RUN mode
	е	Red	Off	No power to module or everything OK
			Double flash	LED indicates one of the following states:
8 🗸 📬				X2X Link power supply is overloaded
8 1 5				I/O supply too low
8 5				Input voltage for X2X Link supply too low
2	e + r	Red on / Greer	n single flash	Invalid firmware
×	Х	Orange	Off	No communication at the X2X Link
The second se			On	X2X Link communication in progress
	1	Red	Off	X2X Link supply in the acceptable range
			On	X2X Link power supply is overloaded
				Solution: Use an additional feed module X20PS3300

## 6 Pinout



## 7 Connection examples

## With two separate supplies



#### With a supply and jumper



## 8 Derating

The rated output current for the supply is 7.0 W. Derating must be taken into consideration based on mounting orientation.



## **9 Register description**

## 9.1 General data points

In addition to the registers listed in the register description, the module also has other more general data points. These registers are not specific to the module but contain general information such as serial number and hardware version.

These general data points are listed in the "General data points" section of chapter 4 "X20 system modules" in the X20 system user's manual.

## 9.2 Function model 0 - Standard

Register	Name	Data type	Read		W	Write	
			Cyclic	Non-cyclic	Cyclic	Non-cyclic	
0	Module status	USINT	•				
	StatusInput01	Bit 0					
	StatusInput02	Bit 2					
2	SupplyCurrent	USINT	•				
4	SupplyVoltage	USINT	•				

### 9.3 Function model 254 - Bus controller

Register	Offset <sup>1)</sup>	Name	Data type	Read		Write	
				Cyclic	Non-cyclic	Cyclic	Non-cyclic
0	0	Module status	UINT	•			
		StatusInput01	Bit 0	]			
		StatusInput02	Bit 2				
2	2	SupplyCurrent	UINT	•			
4	4	SupplyVoltage	UINT	•			

1) The offset specifies the position of the register within the CAN object.

### 9.4 Module status

Name:

Module status

The following voltage and current states of the module are monitored in this register:

Bus supply current:	A bus supply current of >2.3A is displayed as a warning.
Bus supply voltage:	A bus supply voltage of <4.7V is displayed as a warning.
24 VDC I/O supply voltage:	An I/O supply voltage of <20.4 V is displayed as a warning.

Function model	Data type	Value
0 - Standard	USINT	See bit structure.
254 - Bus controller	UINT	See bit structure.

#### Bit structure:

Bit	Name	Value	Information
0	StatusInput01	0	No error
		1	Warning - overcurrent (>2.3 A) or undervoltage (<4.7 V)
1	Reserved	0	
2	StatusInput02	0	I/O supply above the warning level of 20.4 V
		1	I/O supply below the warning level of 20.4 V
3 - x	Reserved	0	

## 9.5 Bus supply current

Name: SupplyCurrent

This register displays the bus supply current measured at a resolution of 0.1 A.

Function model	Data type
0 - Standard	USINT
254 - Bus controller	UINT

#### 9.6 Bus supply voltage

Name: SupplyVoltage

This register displays the bus supply voltage measured at a resolution of 0.1 V.

Function model	Data type
0 - Standard	USINT
254 - Bus controller	UINT

### 9.7 Minimum cycle time

The minimum cycle time defines how far the bus cycle can be reduced without communication errors occurring. It should be noted that very fast cycles decrease the idle time available for handling monitoring, diagnostics and acyclic commands.

Minimum cycle time 100 µs

#### 100

### 9.8 Minimum I/O update time

The minimum I/O update time defines how far the bus cycle can be reduced while still allowing an I/O update to take place in each cycle.

Minimum I/O update time 2 ms